



MAIN FUSE BLOCK



FUSE NO.	FUSE DESCRIPTION	FUSE CAPACITY
1	HEATER	60A
2	ABS PUMP	60A
3	COOLING FAN	40A
4	BTN (MAIN)	60A
5	MAIN	80A
6	HEAD	30A
7	RETRA	30A
8	FUEL INJ.	30A
9	AUDIO	10A
10	AIR COND.	15A

JOINT BOX AND  
MAIN FUSE BLOCK