

28

29

30

31

32

33

CRANKSHAFT  
POSITION  
SENSOR  
(GT ONLY)



TO  
GROUND


BOOST  
SENSOR  
(GT ONLY)



POWER STEERING  
SOLENOID VALVE  
(GT ONLY)



RADIATOR  
TEMP. SWITCH  
(GT ONLY)



C208

A

B

C

D

E

F

28

29

30

31

32

33